



PM-Series Door Template Index



[P1](#): PM-Series Lock Case Dimensions

[P2](#): PM-Series Door Edge Preps

Function	Sectional	Escutcheon	Deadbolt
PM010	P105	P106	—
PM026	P107	P108	—
PM040	P109	P110	—
PM044	P109	—	—
PM050	P111	P112	—
PM056	P111	P112	—
PM060	P113	P114	—
PM071	P113	P114	—
PM080	P115	P116	—
PM081	P115	P116	—
PM090	P118	P119	—
PM091	P118	P119	—
PM092	P120	P121	—
PM175	P101	P102	—
PM176	P103	P104	—
PM440	P109	P110	—
PM444	P109	P110	—
PM453	P111	P112	—
PM456	P111	P112	—
PM457	P113	P114	—
PM460	—	—	P117
PM462	—	—	P117
PM463	—	—	P117
PM464	—	—	P117
PM485	P111	P112	—
PM092	P120	P121	—